



# IDS Lift-Net Tech Support

## Network Transfer of APPLICATION AND CONFIGURATION FILE UPDATES

*Note: "jobname" will be files and folders within the "lift\_net" folder that correspond to the building or complex name or address.*

Distributing config files via Ethernet using Lift-Net "Network Administration"

1. Click System, Network Administration, Options and File Dates for All Sites.
2. Click the Connect button for each site. This should display the current file dates for each network site. Dates in "RED" are older than dates in "GREEN".
3. Select a site and Click Change, Lift-Net Files.
4. To transfer Liftnet2.zip, otherln.zip, or *jobname*.zip files
5. Click SEND or RECEIVE ????.zip files. Confirm sending or receiving zip files from this computer to (other computer). Click YES.
6. When send or receive is complete Click Restart. To restart the remote computer.
7. Repeat steps 3 – 6 for all network sites.
8. Click the Connect button for each site to verify the remote computers have restarted.

Good Luck,

**Sam "C"**  
**Lift-net Tech Support**  
**847 530-2413**